











Original	Recharge
Power	Power
Volume-	Vol-
Volume+	Vol+
LD/VCR	Red / Netflix / Search
LD/VCR	4
Phono	Green / APP / Repeat
Phono	2
CD Direct	Yellow / YouTube / Repeat
CD Direct	3
Surround	Eject / Surround
Surround	Blue / Prime Video / Random
< Deck 1	Left
Deck 1 >	Right
<< Deck 1	Down
Deck 1 >>	Up
Stop Deck 1	OK
< Deck 2	Shift + Left

Original	Recharge
Deck 2 >	Shift + Right
<< Deck 2	Shift + Down
Deck 2 >>	Shift + Up
Rec Deck 2	Shift + Rec / Rec Mode
Pause Deck 2	Shift + Pause / Step / Freeze
Stop Deck 2	Shift + OK
Tuner Station -	CH- / Page-
Tuner Station -	Shift + I<< / Preset-
Tuner Station +	CH+ / Page+
Tuner Station +	Shift + >>I / Preset+
Disc CD	D.Menu / Top
Play CD	Play / Slow
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
Sound Control On/Off	Sound / Title





	Original	Rechange
	Call	 Audio / Lang I/II
	Sleep	 Sleep / Timer
	Wake Up	 Display / Media
	Snooze	 Smart / List

	Original	Rechange













Original	Recharge
Power	Power
Volume-	Vol-
Volume+	Vol+
LD/VCR	Red / Netflix / Search
LD/VCR	4
Phono	Green / APP / Repeat
Phono	2
CD Direct	Yellow / YouTube / Repeat
CD Direct	3
Surround	Eject / Surround
Surround	Blue / Prime Video / Random
< Deck 1	Left
Deck 1 >	Right
<< Deck 1	Down
Deck 1 >>	Up
Stop Deck 1	OK
< Deck 2	Shift + Left

Original	Recharge
Deck 2 >	Shift + Right
<< Deck 2	Shift + Down
Deck 2 >>	Shift + Up
Rec Deck 2	Shift + Rec / Rec Mode
Pause Deck 2	Shift + Pause / Step / Freeze
Stop Deck 2	Shift + OK
Tuner Station -	CH- / Page-
Tuner Station -	Shift + I<< / Preset-
Tuner Station +	CH+ / Page+
Tuner Station +	Shift + >>I / Preset+
Disc CD	D.Menu / Top
Play CD	Play / Slow
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
Sound Control On/Off	Sound / Title





Original	Rechange	Original	Rechange
 Call	 Audio / Lang I/II		
 Sleep	 Sleep / Timer		
 Wake Up	 Display / Media		
 Snooze	 Smart / List		

