



Original	Recharge
 Power	 Power
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 I / II	 Dual
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 CH.List	 List
 Recall	 Back

Original	Recharge
 Source	 AV
 Menu	 Menu
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Info	 Info
 Exit	 Exit
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 Aspect	 Format
 CH +	 Ch +
 CH -	 Ch -
 Play/Pause / EPG	 Guide
 Play/Pause / EPG	 Play



