



| Original | Recharge |
|---|---------------|
| PP | PP |
|  | Back / Return |
|  | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| P<P | P<P |
| 0 | 0 |
| -- | -- |
|  | Menu [M] |
|  | Info [i] |
|  | I-II |

| Original | Recharge |
|---|------------------|
|  | Mute |
|  | Left |
|  | Up |
|  | Right |
|  | OK |
|  | Down |
|  | V - |
|  | V + |
|  | P - |
|  | P + |
|  | Red / Sound |
|  | Green / Picture |
|  | Yellow / Feature |
|  | Blue / Install |
|  | Text |



