







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol-		Vol -
	Source		AV		PR+		Ch +
	1		1		PR-		Ch -
	2		2		Menu		Menu
	3		3		Home		Smart
	4		4		Content		Media
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	TTX/MIX		Text		Enter		Ok
	Guide		Guide		Return		Back
	Mute		Mute		Exit		Exit
	CH.List		List		Red/A		Red
	Vol+		Vol +		Green/B		Green





Original	Rechange	Original	Rechange
 Yellow/C	 Yellow		
 Blue/D	 Blue		
 Alarm	 Dual		
 3D	 3D		
 Subt.	 Subt		
 Stop	 Stop		
 <</ <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>/>>	 >>		

