



Original	Rechange	Original	Rechange
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	CH List	List
2	2	Smart Hub	Smart
3	3	Menu	Menu
4	4	Search	TV/R
5	5	Tools	Options
6	6	Info	Info
7	7	Return	Back
8	8	Exit	Exit
9	9	Up	Up
0	0	Down	Down
TTX/MIX	Text	Right	Right
PRE-CH	Pre Ch	Left	Left
Vol+	Vol +	Enter	Ok
Vol-	Vol -	Red	Red
Mute	Mute	Green	Green

Original	Rechange	Original	Rechange
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	CH List	List
2	2	Smart Hub	Smart
3	3	Menu	Menu
4	4	Search	TV/R
5	5	Tools	Options
6	6	Info	Info
7	7	Return	Back
8	8	Exit	Exit
9	9	Up	Up
0	0	Down	Down
TTX/MIX	Text	Right	Right
PRE-CH	Pre Ch	Left	Left
Vol+	Vol +	Enter	Ok
Vol-	Vol -	Red	Red
Mute	Mute	Green	Green



