







































Original		Recharge	
	Power		Power
	123		1
	Colors		Green / APP / Repeat
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Ok		OK
	Back		Back / Return
	Home		Menu / Home
	Play/Pause		Play / Slow
	Vol+		Vol+
	Vol-		Vol-
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Netflix		Red / Netflix / Search
	Prime video		Blue / Prime Video / Random

Original		Recharge	
	Rakuten Tv		Yellow / YouTube / Repeat

