
















































| Original | Recharge | |
|-------------|---|---------------|
| On/Off |  | Power |
| Next |  | >>I |
| Audio Out |  | Mute |
| Slow Down |  +  | Shift + << |
| F.Adv |  +  | Shift + Media |
| Mon/TV |  | Subt |
| Sp/Lp/Speed |  | Eject |
| Stop |  | Stop |
| Slow/Dpss- |  +  | Shift + Ch - |
| Auto/Track |  | Smart |
| Video/Go-To |  | D. Menu |
| Slow/Dpss+ |  +  | Shift + Ch + |
| Pause |  | Pause |
| Menu |  | Menu |
| VCR/TV |  | Media |
| Menu Up |  | Up |
| Display |  | Info |

| Original | Recharge | |
|-------------|---|-------|
| Menu Left |  | Left |
| OK Enter |  | Ok |
| Menu Right |  | Right |
| Exit |  | Exit |
| Menu Down |  | Down |
| T.Set/Clock |  | Back |
| Tracking+ |  | Vol + |
| Tracking- |  | Vol - |
| Prev. |  | I<< |
| Audio |  | Dual |
| 1 |  | 1 |
| 2 |  | 2 |
| 3 |  | 3 |
| 4 |  | 4 |
| 5 |  | 5 |
| 6 |  | 6 |
| 7 |  | 7 |



| Original | Recharge | |
|---------------|---|---------------|
| 8 |  | 8 |
| 9 |  | 9 |
| -/-- |  | Guide |
| 0 |  | 0 |
| Progr/C/CH |  | Pre Ch |
| Store |  +  | Shift + Smart |
| Rewind |  | << |
| Case Tape |  | 3D |
| Next Sv+V |  +  | Shift + >>I |
| Play |  | Play |
| Vps/Pdc |  | Format |
| F.Forward |  | >> |
| Search Index |  | TV/R |
| Record |  | Rec |
| Encode |  | Options |
| On/Off |  +  | Shift + Power |
| Counter Clock |  | Red |

| Original | Recharge | |
|---------------|---|--------------|
| Counter/Memor |  | Green |
| Input Source |  | AV |
| Counter Reset |  | Yellow |
| Skip/Search |  +  | Shift + TV/R |
| Info/Intro |  +  | Shift + Info |
| Repeat |  | Text |
| Audio Dub |  +  | Shift + Dual |
| Frame Up |  | Ch + |
| Timer/Record |  +  | Shift + AV |
| Frame Down |  | Ch - |
| Timer/Sleep |  | Sleep |
| X2 Rew/Play |  | List |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

