







































































| Original | | Recharge | | Original | | Recharge | |
|---|----------|---|---------------------------|---|------------|---|-------------------|
|  | Standby |  | Power |  | 5 |  | 5 |
|  | DVD |  | Shift + 2 |  | 6 |  | 6 |
|  | Tuner |  | Shift + 6 |  | Display |  | Display / Media |
|  | AUX |  | Shift + 7 |  | 7 |  | 7 |
|  | Subtitle |  | Subtitle / EQ |  | 8 |  | 8 |
|  | Language |  | Shift + Audio / Lang I/II |  | 9 |  | 9 |
|  | Title |  | Sound / Title |  | NTSC/PAL |  | Picture / Format |
|  | Return |  | Back / Return |  | +10 |  | Guide / EPG / -/- |
|  | Goto |  | Text / Goto |  | 0 |  | 0 |
|  | Zoom |  | Zoom / Size |  | Sleep |  | Sleep / Timer |
|  | Menu/PBC |  | Menu / Home |  | Mute |  | Mute / Dimmer |
|  | Angle |  | Info / Angle |  | Setup |  | Setup / OPT / |
|  | 1 |  | 1 |  | Open/Close |  | Eject / Surround |
|  | 2 |  | 2 |  | Up |  | Up |
|  | 3 |  | 3 |  | Left |  | Left |
|  | Audio |  | Audio / Lang I/II |  | Enter |  | OK |
|  | 4 |  | 4 |  | Right |  | Right |



