



Original	Recharge	Original	Recharge
 Power	 Power	 -[J]- / S.STD	 Shift + Dual
 Sleep	 Sleep	 Menu	 Menu
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Vol +	 Vol +
 6	 6	 Vol -	 Vol -
 7	 7	 Program +	 Ch +
 8	 8	 Program -	 Ch -
 9	 9	 Exit	 Exit
 0	 0	 Open / Close	 Eject
 10+ / Aspect	 Shift + Guide	 Info	 Info
 Subtitle	 Subt	 Setup / DVD / FAV	 Options
 Source	 AV	 I/II / Audio	 Dual
 -[/]- / P.STD	 Shift + Format	 [/≡] / Text	 Text





	Original	Recharge	Original	Recharge
	Play	 Play	 Blue	 Blue
	Pause	 Pause		
	Stop	 Stop		
	[≡x] / EPG	 GUIDE		
	[≡◆] / Title / ADD	 TV/R		
	Menu / SUB.	 D. Menu		
	[≡+] / Goto	 Format		
	[≡?] / Slow	 Smart		
	[≡o] / Repeat	 3D		
	[≡i] / A-B	 Media		
	I<<	 I<<		
	Red	 Red		
	>>I	 >>I		
	Green	 Green		
	<<	 <<		
	Yellow	 Yellow		
	>>	 >>		

