



Original		Rechange		Original		Rechange	
	CD 1		1		Tape		Green
	CD 2		2		On/Standby		Power
	CD 3		3		X-Bass		Dual
	Memory Set		Menu		Vol-		Vol -
	Pause CD		Pause		Vol+		Vol +
	Stop		Stop				
	Play/Back		Play				
	Clear		Exit				
	Random		Media				
	I<</Preset		I<<				
	>>I/Preset Up		>>I				
	Equalizer Mode		Subt				
	Clock		AV				
	Timer		Text				
	Sleep		Sleep				
	CD		Yellow				
	Tuner/Band		Red				

