



Original	Recharge
 Power	 Power
 Text	 Text / Goto
 [≡?]	 Fav / Marker / PC
 Subtitles	 Subtitle / EQ
 [≡+]	 Sound / Title
 [≡o]	 Shift + Picture / Format
 Size	 Zoom / Size
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Recall	 Back / Return

Original	Recharge
 0	 0
 Source	 AV / Input / RDS
 DTV	 Display / Media
 EPG	 Guide / EPG / -/-
 ESG	 Shift + Zoom /
 Radio	 TV/Radio /
 Audio I / II	 Audio / Lang I/II
 Vol +	 Vol+
 P +	 CH+ / Page+
 AV Mode	 Setup / OPT /
 Mute	 Mute / Dimmer
 Vol -	 Vol-
 P -	 CH- / Page-
 Surround	 Eject / Surround
 DTV Menu	 D.Menu / Top
 List	 Smart / List
 Info	 Info / Angle



