































































Original	Recharge	Original	Recharge
 ON/OFF	 Power	 Vol-	 Vol -
 Freeview Play	 Options	 Mute	 Mute
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 Menu	 Menu
 4	 4	 Exit	 Exit
 5	 5	 Back	 Back
 6	 6	 FAV	 Pre Ch
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Tv Guide	 Guide	 OK	 Ok
 Picture	 Format	 Info	 Info
 Sound	 Dual	 Text	 Text
 Source	 AV	 Subtitle	 Subt
 Vol+	 Vol +	 TV	 TV/R





Original		Recharge		Original		Recharge	
	You Tube		Media				
	Netflix		Smart				
	APPS		Shift + Media				
	Rec/DVD Menu		Rec				
	I<<		I<<				
	>>I		>>I				
	Stop		Stop				
	Rec List/DVD		D. Menu				
	<<		<<				
	>>		>>				
	Play		Play				
	Pause		Pause				
	Red/Goto		Red				
	Green/A-B		Green				
	Yellow/Angle		Yellow				
	Blue/Repeat		Blue				

