



Original	Recharge	Original	Recharge
On/Standby	Power	Band	TV/Radio /
Stop	Stop / Hold	X-Bass/Equalizer	Sound / Title
Play	Play / Slow	3D Surround	Audio / Lang I/II
Pause	Pause / Step / Freeze	Vol-	Vol-
Back/Random	Back / Return	Vol+	Vol+
I<</<</Preset-	I<< / Preset-		
Preset+>>>/>>>	>>I / Preset+		
Memory/Set	Setup / OPT /		
Tuning-	<< / Tune-		
Tuning+	>> / Tune+		
Clear	Exit / Cancel / Clear		
Timer/Set	D.Menu / Top		
Timer	Shift + Sleep / Timer		
Sleep	Sleep / Timer		
Timer-	Down		
Timer+	Up		
Function	Menu / Home		

