



Original	Rechange	Original	Rechange
Source	AV / Input / RDS	Teletext	Text / Goto
Sync Menu	Setup / OPT /	Red	Red / Netflix / Search
Power	Power	Green	Green / APP / Repeat
Digital/Analog	Display / Media	Yellow	Yellow / YouTube / Repeat
Tv/Radio	TV/Radio /	Blue	Blue / Prime Video / Random
Football	Eject / Surround	[i+]/[?]	Info / Angle
1	1	Netflix	Shift + Red / Netflix /
2	2	Help	Sleep / Timer
3	3	TV	Shift + 1
4	4	Action Menu	D.Menu / Top
5	5	Up	Up
6	6	Guide	Guide / EPG / -/--
7	7	Left	Left
8	8	OK	OK
9	9	Right	Right
Exit	Exit / Cancel / Clear	Back	Back / Return
0	0	Down	Down



