








































































































Original	Rechange	Original	Rechange
 Source	 AV / Input / RDS	 Teletext	 Text / Goto
 Sync Menu	 Setup / OPT /	 Red	 Red / Netflix / Search
 Power	 Power	 Green	 Green / APP / Repeat
 Digital/Analog	 Display / Media	 Yellow	 Yellow / YouTube / Repeat
 Tv/Radio	 TV/Radio /	 Blue	 Blue / Prime Video / Random
 Football	 Eject / Surround	 [i+]/[?]	 Info / Angle
 1	 1	 Netflix	 Shift + Red / Netflix /
 2	 2	 Help	 Sleep / Timer
 3	 3	 TV	 Shift + 1
 4	 4	 Action Menu	 D.Menu / Top
 5	 5	 Up	 Up
 6	 6	 Guide	 Guide / EPG / -/-
 7	 7	 Left	 Left
 8	 8	 OK	 OK
 9	 9	 Right	 Right
 Exit	 Exit / Cancel / Clear	 Back	 Back / Return
 0	 0	 Down	 Down





Original		Rechange		Original		Rechange	
	Home		Menu / Home		Rec		Rec / Rec Mode
	Discover		Fav / Marker / PC		Stop		Stop / Hold
	Vol+		Vol+		Title List		Smart / List
	O		Picture / Format				
	PR+		CH+ / Page+				
	Vol-		Vol-				
	Mute		Mute / Dimmer				
	PR-		CH- / Page-				
	Audio		Audio / Lang I/II				
	[...]		Subtitle / EQ				
	[+]		Zoom / Size				
	<<		<< / Tune-				
	Play		Play / Slow				
	>>		>> / Tune+				
	I<<		I<< / Preset-				
	Pause		Pause / Step / Freeze				
	>>I		>>I / Preset+				

