







































































Original		Rechange		Original		Rechange	
	Standby Tv		Power		*		Options
	Mute		Mute		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Menu		Menu
	8		8		Prog+		Ch +
	9		9		Prog-		Ch -
	0		0		Red		Red
	[i+]/[?]		Info		Green		Green
	Recall/-/--		Pre Ch		Yellow		Yellow
	[≡]		Text		Blue		Blue
	[ ]		Guide		Stop		Stop
	♪		Dual		<<		<<





	Original	Rechange		Original	Rechange
	Play	 Play			
	>>	 >>			
	[+]	 3D			
	Source	 AV			
	[  ]	 Subt			
	[ ]	 TV/R			
	[<>]	 Format			

	Original	Rechange

