

































































































Original		Recharge		Original		Recharge	
	Power		Power		Green		Green
	Input		AV		Yellow		Yellow
	Digital/Analog		TV/R		Blue		Blue
	Sync Menu		Menu		YouTube		Media
	1		1		Netflix		Shift + Media
	2		2		Sleep		Sleep
	3		3		Info		Info
	4		4		Guide		Guide
	5		5		Options		Options
	6		6		Home		Smart
	7		7		Return		Back
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Exit		Exit		Left		Left
	[≡]		Text		Ok		Ok
	Red		Red		Vol+		Vol +





Original		Recharge		Original		Recharge	
	Vol-		Vol -				
	Mute		Mute				
	Recall		Pre Ch				
	CH+		Ch +				
	CH-		Ch -				
	Audio		Dual				
	[...]		Subt				
	Title List		List				
	<<		<<				
	Play		Play				
	>>		>>				
	I<<		I<<				
	Pause		Pause				
	>>I		>>I				
	Rec		Rec				
	Stop		Stop				
	[+]		3D				

