




































































Original	Rechange	Original	Rechange
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up / CH + / I<<	 Up
 3	 3	 Down / CH - / >>I	 Down
 4	 4	 Right / Vol +	 Right
 5	 5	 Left / Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 Up / CH + / I<<	 I<<
 8	 8	 Down / CH - / >>I	 >>I
 9	 9	 Up / CH + / I<<	 Ch +
 0	 0	 Down / CH - / >>I	 Ch -
 FAV	 Shift + Pre Ch	 Left / Vol -	 Vol -
 Recall	 Pre Ch	 Right / Vol +	 Vol +
 Game	 Media	 Red / Zoom	 Red
 Auto	 Smart	 Green / Lan/Audio	 Green
 Info	 Info	 Yellow /	 Yellow

Original	Rechange	Original	Rechange
 MUTE	 MUTE	 TV	 AUX
 MUTE	 MUTE	 DVD	 SAT
 1	 1	 SOUND	 AD
 2	 2	 PICTURE	 ECO
 3	 3	 REPEAT	 ZOOM
 4	 4	 DUAL	 FORMAT
 5	 5	 SUBT	 OPT
 6	 6	 SLEEP	 3D
 7	 7	 E-MANUAL	 TIMER
 8	 8	 D.MENU	 TEXT
 9	 9	 TOP MENU	 DISPLAY
 0	 0	 MENU	 INFO
 FAV	 FAV	 OK	 OK
 Recall	 Recall	 EXIT	 BACK
 GAME	 GAME	 HOME	 HOME
 AUTO	 AUTO	 SMART	 SMART
 INFO	 INFO	 APP	 APP
 POWER	 POWER	 MEDIA	 MEDIA
 1	 1	 + CH	 + CH
 2	 2	 CH -	 CH -
 3	 3	 VOL -	 VOL -
 4	 4	 VOL +	 VOL +
5	5	ZOOM	ZOOM
6	6	LAN/AUDIO	LAN/AUDIO
7	7	PLAY/PAUSE	PLAY/PAUSE
8	8	A	A
9	9	B	B
0	0	C	C
FAV	FAV	D	D



Play/Pause

