

























































| Original | Recharge |
|---|--|
|  Power |  Power |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Mute |  Mute / Dimmer |
|  Return |  Back / Return |
|  PR+ |  CH+ / Page+ |
|  >> |  >> / Preset+ |
|  << |  << / Preset- |
|  PR- |  CH- / Page- |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  Up |  Up |
|  Down |  Down |
|  Right/Zoom+ |  Right |
|  Left/Zoom- |  Left |
|  OK |  OK |
|  Red |  Red / Netflix / Search |


| Original | Recharge |
|--|---|
|  Sound |  Sound / Title |
|  Green |  Green / APP / Repeat |
|  List |  Shift + Smart / List |
|  Yellow |  Yellow / YouTube / Repeat |
|  Info |  Info / Angle |
|  Mosaic |  Smart / List |
|  Blue |  Blue / Prime Video / Random |
|  Violet |  Display / Media |
|  Text |  Text / Goto |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |








| Original | Recharge | Original | Recharge |
|--|--|----------|----------|
|  9 |  9 | | |
|  0/-/- |  0 | | |
|  AV |  AV / Input / RDS | | |
|  PIP |  Zoom / Size | | |
|  <</Pat-Mix |  << / Tune- | | |
|  Play/? |  Play / Slow | | |
|  >> |  >> / Tune+ | | |
|  Rec/100 |  Rec / Rec Mode | | |
|  Stop |  Stop / Hold | | |
|  Pause/---- |  Pause / Step / Freeze | | |
|  Swap PIP |  Setup / OPT / | | |
|  Size PIP |  Picture / Format | | |
|  Position PIP |  TV/Radio / | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |


















| Original | Rechange |
|---|--|
|  Power |  Power |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Mute |  Mute / Dimmer |
|  Return |  Back / Return |
|  PR+ |  CH+ / Page+ |
|  >> |  >> / Preset+ |
|  PR- |  CH- / Page- |
|  << |  << / Preset- |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  Up |  Up |
|  Down |  Down |
|  Right/Zoom+ |  Right |
|  Left/Zoom- |  Left |
|  OK |  OK |
|  Red |  Red / Netflix / Search |


| Original | Rechange |
|--|--|
|  Sound |  Sound / Title |
|  Green |  Green / APP / Repeat |
|  List |   +  Shift + Smart / List |
|  Info |  Info / Angle |
|  Yellow |  Yellow / YouTube / Repeat |
|  Mosaic |  Smart / List |
|  Blue |  Blue / Prime Video / Random |
|  Violet |  Display / Media |
|  Text |  Text / Goto |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |







































| Original | | Rechange | | Original | | Rechange | |
|---|--------------|---|-----------------------|----------|--|----------|--|
|  | 9 |  | 9 | | | | |
|  | 0/-/-- |  | 0 | | | | |
|  | AV |  | AV / Input / RDS | | | | |
|  | PIP |  | Zoom / Size | | | | |
|  | <</Pat-Mix |  | << / Tune- | | | | |
|  | Play/? |  | Play / Slow | | | | |
|  | >> |  | >> / Tune+ | | | | |
|  | Rec/100 |  | Rec / Rec Mode | | | | |
|  | Stop |  | Stop / Hold | | | | |
|  | Pause/---- |  | Pause / Step / Freeze | | | | |
|  | Swap PIP |  | Setup / OPT / | | | | |
|  | Size PIP |  | Picture / Format | | | | |
|  | Position PIP |  | TV/Radio / | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Recharge |
|---|--|
|  Power |  Power |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Mute |  Mute / Dimmer |
|  Return |  Back / Return |
|  PR+ |  CH+ / Page+ |
|  >> |  >> / Preset+ |
|  << |  << / Preset- |
|  PR- |  CH- / Page- |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  Up |  Up |
|  Down |  Down |
|  Right/Zoom+ |  Right |
|  Left/Zoom- |  Left |
|  OK |  OK |
|  Red |  Red / Netflix / Search |

| Original | Recharge |
|--|---|
|  Sound |  Sound / Title |
|  List |  Shift + Smart / List |
|  Green |  Green / APP / Repeat |
|  Info |  Info / Angle |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  Mosaic |  Smart / List |
|  Violet |  Display / Media |
|  Text |  Text / Goto |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |



