




































































Original		Rechange		Original		Rechange	
	Mute		Mute / Dimmer		Source		AV / Input / RDS
	Power		Power		Vol -		Vol-
	1		1		Vol +		Vol+
	2		2		CH -		CH- / Page-
	3		3		CH +		CH+ / Page+
	Sleep		Sleep / Timer		Info		Info / Angle
	4		4		Nicam/A2 / Audio		Audio / Lang I/II
	5		5		Auto		Setup / OPT /
	6		6		P.Mode		Picture / Format
	Still		Eject / Surround		Up		Up
	7		7		Menu		Menu / Home
	8		8		Left		Left
	9		9		OK		OK
	Aspect		Zoom / Size		Right		Right
	-/--		Guide / EPG / -/--		S.Mode		Sound / Title
	0		0		Down		Down
	Prev. Ch.		Back / Return		Exit		Exit / Cancel / Clear





Original	Recharge
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	I<< / Index
	>>I / Cancel
	<< / Reveal
	>> / Hold
	Txt / Goto
	Play/Pause / Size
	Play/Pause / Size
	Stop / Subpage
	Subtitle / EQ
	Rec Menu / Shift + Rec / Rec Mode
	CH List / Smart / List
	FAV / Marker / PC
	USB / Shift + 8

Original	Recharge
	DTV / Radio / TV/Radio /
	DTV / D.Menu / Top
	REC / Repeat / Rec / Rec Mode

