



Original	Rechange
Power	Power
Mute	Mute / Dimmer
Menu	Menu / Home
1	1
2	2
3	3
Audio	Audio / Lang I/II
OSD	Display / Media
4	4
5	5
6	6
Setup	Setup / OPT /
Angle	Info / Angle
7	7
8	8
9	9
Subtitle	Subtitle / EQ

Original	Rechange
Program	TV/Radio /
0/10	0
10+	Guide / EPG / -/-
Time	Shift + Sleep / Timer
Title	Sound / Title
Step/RDS	Text / Goto
Repeat	Green / APP / Repeat
Zoom	Zoom / Size
A-B	Yellow / YouTube / Repeat
P.EQ	AV / Input / RDS
Darkness	Back / Return
Loudness	Smart / List
S-Bass	Picture / Format
<< / TU-	<< / Tune-
Vol-	Vol-
Vol+	Vol+
>> / TU+	>> / Tune+



