



Original	Recharge
 Power	 Power
 Mute	 Mute
 Display	 Info
 Mode	 List
 Timer	 AV
 TV/R	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 D. Menu

Original	Recharge
 F1	 Shift + 1
 FUNC	 3D
 Sub	 Subt
 [++]	 Format
 TXT	 Text
 Find	 Shift + TV/R
 EPG	 Guide
 Pause	 Shift + Pause
 Sleep	 Sleep
 Red/Audio	 Red
 Green/Recall	 Green
 Yellow/Zoom	 Yellow
 Blue/Info	 Blue
 FAV	 Pre Ch
 Help	 Dual
 Menu	 Menu
 Exit	 Exit



