



Original	Rechange
 Standby/On	 Power
 STB	 Green
 VCR	 Yellow
 DVD	 Blue
 AUX	 Red
 TV	 TV/R
 Vol Mode	 Dual
 Auto Setup	 Media
 Input Mode	 AV
 Sleep	 Sleep
 1/5Beam	 1
 2/ST+3Beam	 2
 3/3Beam	 3
 4/Stereo	 4
 5/My Beam	 5
 6/My Sur.	 6
 Sur. Decode	 Options

Original	Rechange
 CH Level	 Smart
 Menu	 Menu
 Return	 Back
 Test	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute





Original	Rechange
 Power Tv	 Power
 STB	 Green
 VCR	 Yellow
 DVD	 Blue
 AUX	 Red
 TV	 TV/R
 Input 1 Tv	 Text
 Input 2 Tv	 Eject
 Vol. Mode	 Dual
 Auto Setup	 Media
 Input Mode	 Format
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5

Original	Rechange
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Sur.Decode	 Options
 CH Level	 Smart
 Menu	 Menu
 Return	 Back
 Test	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 CH+	 Ch +





Original		Rechange		Original		Rechange	
	CH-		Ch -				
	Tv Input		AV				
	Tv Vol+		Vol +				
	Tv Vol-		Vol -				
	Tv Mute		Mute				
	<<		<<				
	Stop		Stop				
	>>		>>				
	I<<		I<<				
	Pause		Pause				
	>>I		>>I				
	Play		Play				





	Original	Rechange	Original	Rechange
	Power			
	Vol+			
	Vol-			
	Mute			
	STB			
	VCR			
	DVD			
	AUX			
	TV			
	<<			
	Stop			
	>>			
	I<<			
	Pause			
	>>I			
	Play			





Original		Rechange		Original	Rechange
	Power AV		Power		
	Vol+		Vol +		
	Vol-		Vol -		
	Mute		Mute		
	STB		Green		
	AUX		Red		
	VCR		Yellow		
	DVD		Blue		
	TV		TV/R		
	<<		<<		
	Stop		Stop		
	>>		>>		
	Pause		Pause		
	Play		Play		

