







































































Original	Recharge	Original	Recharge
 Power	 Power	 prime video	 Shift + Media
 Smart	 Smart	 Home	 Shift + Smart
 1	 1	 Menu	 Menu
 2	 2	 Back	 Back
 3	 3	 Exit	 Exit
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 Info	 Info	 Mute	 Mute
 Guide	 Guide	 CH+	 Ch +
 Netflix	 Media	 CH-	 Ch -
 YouTube	 Options	 Source	 AV
 Google Play	 3D	 Red	 Red





Original	Recharge	Original	Recharge
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 <<	 <<		
 Play	 Play		
 >>	 >>		
 Rec	 Rec		
 Pause	 Pause		
 Stop	 Stop		
 Text	 Text		
 Subt	 Subt		
 Audio	 Dual		

