Mandis shop

Panasonic YEFX9995601

Original		Replacement	
POWER SRC	Power		Power
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
TRACK	I<< Track/Search		I<<
SEARCH	Track/Search >>I		>>I
MENU	Menu	TOP MENU MENU	Menu
RETURN RET	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
1 SUBTITLE	1/Subtitle	1	1
2 AUDIO	2/Audio	2	2
3 ANGLE	3/Angle	3	3
4 RANDOM	4/Random	4	4

Original		Replacement	
5 SCAN	5/Scan	5	5
6 REPEAT	6/Repeat	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
A ASPECT	Aspect	PICTURE FORMAT	Format
GAME	Game	HOME SMART	Smart
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
OSD TRACK	OSD/Track	REPEAT TEXT	Text
TITLE TITLE / CHAPTER	Title/Title Chapter	SETTINGS OPT	Options

https://telecommandes-mandis.be/en/Panasonic/1057126-9686-replacement-remote-control-for-Panasonic-YEFX9995601.html