Original		Replacement	
Power		Power	
Open / Close		Eject	
Angle		Format	
Zoom		Shift + Eject	
Program		Sleep	
Random		3D	
Repeat		Text	
A - B		TV/R	
<< REV		<<	
>> FWD		>>	
I << Skip		I <<	
>>I Skip		>>I	
Pause		Pause	
Play		Play	
Stop		Stop	
Clear		Exit	
Disc Menu		D. Menu	

Original		Replacement	
Up		Up	
Right		Right	
Down		Down	
Left		Left	
OK		Ok	
Preview		Smart	
Set Up		Options	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	

Original		Replacement	
DISPLAY	Display	DISPLAY INFO	Info
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
	Mute	MUTE	Mute
BOOKMARK	Bookmark	FAV PRE-CH	Pre Ch
TITLE MENU	Title Menu	TOP MENU MENU	Menu

Original	Replacement