Mandis shop

RMT-AH410U

Original	Replacement
Power	Power
Input	AV
Auto Sound	Smart
Standard	Options
Cinema	Media
Music	Dual
Voice	TV/R
Night	Exit
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Bass	Subt
Play Mode	Shift + Play
Audio	Shift + Dual
Up	Up
Down	Down
Enter	Ok

Original	Replacement
Play	Play
Pause	Pause
>>I	>>I
I<<	I<<

https://telecommandes-mandis.be/en/Sony/1061634-92595-replacement-remote-control-for-Sony-RMT-AH410U-1-493-358-11.html