Mandis shop

Sony RM-AMU212

Original	Replacement
Sleep	Sleep / Timer
Timer Menu	Menu / Home
Display	Display / Media
Power	Power
CD	5
USB	8
Bluetooth	9
FM	6
Audio In	7
Bluetooth Menu	D. Menu / Top
Tuner Memory	1
Tuner Memory	2
EQ	Subtitle / EQ
Tuner Memory	3
Tuner Memory	4
Mega Bass	Sound / Title
Tuner Memory	Rec / Rec Mode

Original	Replacement
Up/ Folder +	CH+ / Page+
Play Mode/ Tuning Mode	TV/ Radio /
Muting	Mute / Dimmer
Left	Left
OK	OK
Right	Right
Volume+	Vol +
Return	Back / Return
Down/ Folder -	CH- / Page-
Repeat / FM	Green / APP / Repeat
Volume-	Vol -
I <</ Preset -	I << / Preset -
Pause	Pause / Step / Freeze
>>I / Preset +	>>I / Preset +
<</ Tuning-	<< / Tune-
Play	Play / Slow
>>/ Tuning+	>> / Tune+

Original	Replacement	Original	Replacement
CLEAR Cl ear	CLEAR EXIT CANCEL Exi t / Cancel / Cl ear		
St op	HOLD St op / Hol d		