Mandis shop

MAJ-R90

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
⏻/ON	Power/On	⏻	Power
INFO/BIT-SEL	Info/Bit-Sel	ANGLE INFO	Info / Angle
REC	Rec	REC MODE	Rec / Rec Mode
FUNCTION	Function	HOME MENU	Menu / Home
PLAY/ PAUSE	Play	SLOW	Play / Slow
PLAY/ PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
VOLUME	Volume+	VOL +	Vol+
STOP/ BAND	Stop/Band	HOLD	Stop / Hold
-TUNING	I<</Tuning/File-	PRESET-	I<< / Preset-
	Volume-	VOL −	Vol-
G/FILE+	Tuning/File+/>>I	PRESET+	>>I / Preset+
ALBUM / PR	Album/Preset-	CH PAGE −	CH- / Page-
M / PRESET	Album/Preset+	CH PAGE +	CH+ / Page+
FIND/DAS	Find/Das	LIST SMART	Smart / List
RDS/REPEAT	RDS/Repeat	APP REPEAT	Green / APP / Repeat
PTY/RANDOM	PTY/Random	Prime Video RANDOM	Blue / Prime Video / Random

Original		Replacement	
FM MODE/INTRO	FM Mode/Intro	OK	OK
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
SLEEP/TIMER	Sleep/Timer	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MEMO/CLK ADJ	Memo/CLK.ADJ	PROGRAM TV/ RADIO	TV/Radio /

https://telecommandes-mandis.be/en/Sanyo/1067335-83731-replacement-remote-control-for-Sanyo-MAJ-R90.html