Mandis shop

SB400

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Power | | Power | | |
| | Mute | MUTE | Mute | | |
| | + | + VOL | Vol + | | |
| | - | VOL − | Vol - | | |
| BASS | Bass | APP MEDIA | Media | | |
| | (;) | HOME SMART | Smart | | |
| AUX IN | AUX In | 4 | 4 | | |
| OPTICAL | Optical | 5 | 5 | | |
| HDMI TV | HDMI Tv | 6 | 6 | | |
| HDMI 1 | HDMI 1 | 1 | 1 | | |
| HDMI 2 | HDMI 2 | 2 | 2 | | |
| HDMI 3 | HDMI 3 | 3 | 3 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://telecommandes-mandis.be/en/JBL/1061152-92745-replacement-remote-control-for-JBL-SB400-93040000860.html