Mandis shop

HI SONI C51

Original		Replacement	
3D/AC3	3D/ AC3	CD - STB 3	3
POWER	Power		Power
BASS+	Bass +		Up
CEN+	CEN+	CH PAGE +	CH+ / Page+
VOL+	Vol +	VOL +	Vol +
BASS-	Bass-		Down
CEN-	CEN-	CH PAGE −	CH- / Page-
VOL-	Vol -	VOL −	Vol -

Original	Replacement

https://telecomands.be/NGS-1696968-replacement-remote-control-for-NGS-Hi-Sonic-51.htm