Original		Replacement	
STANDBY	Standby		Power
MUTE	Mute	MUTE	Mute
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
UHF	Red / UHF	A	Red
AUDIO	Green / Audio	B	Green
AUDIO	Green / Audio	SOUND DUAL	Dual
PAUSE	Yellow / Pause	C	Yellow
PAUSE	Yellow / Pause	II	Pause
RECALL	Blue / Recall	D	Blue
RECALL	Blue / Recall	RETURN BACK	Back
1	1	1	1

Original		Replacement	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
EPG	EPG	-/-- GUIDE	Guide
GROUP	Group	FAV PRE-CH	Pre Ch
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL –	Vol -
CH	CH+	+ CH	Ch +
CH	CH-	CH –	Ch -
PAGE	Page+	>>	>>I
PAGE	Page-	<<	I<<

Original		Replacement	
INFO	Info	DISPLAY INFO	Info
SAT/TV	SAT/TV	TIMER AV	AV
SAT/TV	SAT/TV	APP MEDIA	Media

Original	Replacement