Mandis shop

REMCON2136

Original		Replacement	
TUNER	Tuner	TUNER 6	6
CD	CD	CD - STB 3	3
DOWN I<<	I<</Down	PRESET- I<<	I<< / Preset-
UP >>I	>>I/Up	PRESET+ >>I	>>I / Preset+
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
M-UP REPEAT	M-Up/Repeat	APP REPEAT	Green / APP / Repeat
MEMORY CLOCK	Memory/Clock	TIMER SLEEP	Sleep / Timer
STOP	Stop	HOLD ■	Stop / Hold
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
BAND	Band	PROGRAM TV/RADIO	TV/Radio /
POWER	Power	⏻	Power
– VOLUME	Volume-	VOL –	Vol-
VOLUME +	Volume+	+ VOL	Vol+

Original	Replacement

https://telecommandes-mandis.be/en/Roadstar/1067276-96946-replacement-remote-control-for-Roadstar-REMCON2136.html