| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Mute | MUTE | Mute |
| F1 | Red/F1 | A | Red |
| F2 | Green/F2 | B | Green |
| F3 | Yellow/F3 | C | Yellow |
| IPTV | Blue/IPTV | D | Blue |
| | << | | << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | Stop | | Stop |
| | >> | | >> |
| V.FORMAT | V.Format | PICTURE FORMAT | Format |
| RESOLUTION | Resolution | ECO 3D | 3D |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| | Rec | REC MODE | Rec |
| OPTION | Option | SETTINGS OPT | Options |
| AUDIO | Audio | SOUND DUAL | Dual |

| Original | | Replacement | |
|---|---|---|---|
| TEXT | Text | REPEAT TEXT | Text |
| SAT | SAT | HOME SMART | Smart |
| INFO | Info | DISPLAY INFO | Info |
| RECAL | Recall | RETURN BACK | Back |
| MENU | Menu | TOP MENU MENU | Menu |
| EXIT | Exit | CLEAR EXIT | Exit |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | Ok |
| + VOL | Vol+ | + VOL | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| EPG | EPG | -/-- GUIDE | Guide |
| + PAGE | Page+ | + CH | Ch + |
| PAGE − | Page- | CH − | Ch - |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 1 | 1 | 1 | 1 | | |
| 2 | 2 | 2 | 2 | | |
| 3 | 3 | 3 | 3 | | |
| 4 | 4 | 4 | 4 | | |
| 5 | 5 | 5 | 5 | | |
| 6 | 6 | 6 | 6 | | |
| 7 | 7 | 7 | 7 | | |
| 8 | 8 | 8 | 8 | | |
| 9 | 9 | 9 | 9 | | |
| 0 | 0 | 0 | 0 | | |
| SLEEP | Sleep | PROG SLEEP | Sleep | | |
| TV/RADIO | Tv/Radio | SEARCH TV/R | TV/R | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |