Mandis shop

RC- T770L

Original		Rechange	
POWER	Power		Power
LW	LW	A	Red
MW	MW	B	Green
FM	FM	C	Yellow
UP	Tuning Up	+ CH	Ch +
TUNING DOWN	Tuning Down	CH −	Ch -
UP	Volume Up	+ VOL	Vol +
VOLUME DOWN	Volume Down	VOL −	Vol -
PROGRAM	Program	PROG SLEEP	Sleep
STOP	Stop		Stop
PLAY/PAUSE	Play	PLAY MODE	Play
PLAY/PAUSE	Pause		Pause
F SKIP	>>I		>>I
B SKIP	I <<		I <<
MEMORY	Memory	REC MODE	Rec
MUTING	Muting	MUTE	Mute
TAPE	Tape	HOME SMART	Smart

Original		Rechange	
PHONO	Phono	APP MEDIA	Media

https://telecommandes.fr/Aiwa/1387-252-telecommande-de-remplacement-pour-AiwaRC-T770L.htm