Mandis shop

# Yamaha FSR76

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| NET | NET | APP MEDIA | Media |
| 1 | Net Radio 1 | 1 | 1 |
| 2 | Net Radio 2 | 2 | 2 |
| 3 | Net Radio 3 | 3 | 3 |
| TV | TV | A | Red |
| BD/DVD | BD/DVD | B | Green |
| ANALOG | Analog | C | Yellow |
| BLUETOOTH | Bluetooth | D | Blue |
| SURROUND | Surround | SOUND DUAL | Dual |
| STEREO | Stereo | AD SUBT | Subt |
| BASS EXTENSION | Bass Extension | REPEAT TEXT | Text |
| CLEAR VOICE | Clear Voice | CLEAR EXIT | Exit |
| AUDIO DELAY | Audio Delay | PICTURE FORMAT | Format |
| SUBWOOFER + | Subwoofer+ | + CH | Ch + |
| SUBWOOFER - | Subwoofer- | CH - | Ch - |
| VOLUME + | Vol+ | + VOL | Vol + |

| Original | | Rechange | |
|---|---|---|---|
| VOLUME - | Vol- | VOL - | Vol - |
| MUTE | Mute | MUTE | Mute |
| INFO | Info | DISPLAY INFO | Info |
| LEARN | Learn | GUIDE | Guide |
| DIMMER | Dimmer | HOME SMART | Smart |

https://telecommandes-mandis.be/fr/Yamaha/1060881-81691-telecommande-de-remplacement-pour-Yamaha-FSR76-ZU846400.html