Mandis shop

LG AKB75315301

Original		Rechange	
	Power		Power
F	F	TOP MENU MENU	Menu
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
FOLDER	Folder Up	+ CH	Ch +
FOLDER	Folder Down	CH −	Ch -
	I <<		I <<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
REPEAT	Repeat	REPEAT TEXT	Text
INFO	Info	DISPLAY INFO	Info
JUKEBOX	Jukebox	HOME SMART	Smart
LIGHTING	Lighting	APP MEDIA	Media
VOCAL EFFECTS	Vocal Effects	SETTINGS OPT	Options

Original		Rechange	
DELETE	Delete	CLEAR EXIT	Exit

https://telecommande-mandis.be/fr/LG-10278-954-telecommande-de-remplacement-pour-LG-AKB75315301.htm