Mandis shop

JVC RMSUXG6R

Original	Rechange
Open/Close	Eject / Surround
Dimmer	Mute / Dimmer
Power	Power
Active Bass EX.	Subtitle / EQ
Clock/Timer	Shift + Sleep / Timer
Sleep	Sleep / Timer
Bass	Sound / Title
Treble	Audio / Lang I/II
FM Mode	CH+ / Page+
Play Mode	Menu / Home
Repeat	Green / APP / Repeat
Auto Preset	CH- / Page-
PTY/EON	Back / Return
Title/Edit	Info / Angle
Enter	Smart / List
Display/Chara.	Display / Media
Up	Up

Original	Rechange
Cancel	Exit / Cancel / Clear
Left	Left
Set	OK
Right	Right
Play/Pause MD	Pause / Step / Freeze
Down	Down
AUX	7
<> Tape	>> / Tune+
FM/AM	6
Play/Pause CD	Play / Slow
I<<	I<< / Preset-
Stop	Stop / Hold
>>I	>>I / Preset+
Volume+	Vol+
Volume-	Vol-

https://telecommandes-mandis.be/fr/JVC/1065394-12352-telecommande-de-remplacement-pour-JVC-RMSUXG6R.html