Mandis shop

RB-DA1160

Original		Rechange	
⏻/ON	Power/On	⏻	Power
FUNCTION	Function	HOME MENU	Menu / Home
TUNER / BAND	Tuner/Band	TUNER 6	6
⏭	>>I/Tuning+	PRESET+ ⏭	>>I / Preset+
⏮	I<</Tuning-	PRESET- ⏮	I<< / Preset-
TU PRESET	Tu Preset	LIST SMART	Smart / List
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
+ VOL	Vol+	+ VOL	Vol+
VOL –	Vol-	VOL –	Vol-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FM MODE / REPEAT	FM	APP REPEAT	Green / APP / Repeat

Original	Rechange

https://telecommandes-mandis.be/fr/Sanyo/1067333-84994-telecommande-de-remplacement-pour-Sanyo-RB-DA1160.html