Mandis shop

FATMAN DOCK STATION

Original	Rechange
Power ON/Off	Power
Next/Prog+	>>I
Tape 1 Preset	Dual
Vol Rs-/Effect	Subt
Tape 2 Pre./eq	TV/R
Vol Rs+/S.Mode	Format
Preset Pause	Shift + Pause
CD/Theater	Smart
Prev./Prog-	I<<
Mute	Mute
Woofer/Speed	3D
Tape 1 Stop	Shift + Stop
Tape 1 Hall/Ats	List
Funct./Direct	Media
Program	Shift + Sleep
Mode	Options
Sleep	Sleep

Original	Rechange
CD Play	Play
Next/Prog+	Ch +
Tape 1 F.FWD	Shift + >>
Tape 1 Rew	Shift + <<
Tape 1 Play	Shift + Play
Display	Info
Volume+	Vol +
CD Rewind	<<
Volume-	Vol -
CD F.FWD	>>
Prev./Prog-	Ch -
CD Pause	Pause