Mandis shop

Hitachi HL02227

Original		Rechange	
	Power		Power
VIDEO	Video	D	Blue
COMPUTER	Computer	C	Yellow
SEARCH	Search	SEARCH TV/R	TV/R
ASPECT	Aspect	PICTURE FORMAT	Format
AUTO	Auto	A	Red
BLANK	Blank	B	Green
MAGNIFY ON	Magnify On	>>	>>
OFF	Magnify Off	<<	<<
HOME	Home	HOME SMART	Smart
END	End	APP MEDIA	Media
PAGE UP	Page Up	+ CH	Ch +
PAGE DOWN	Page Down	CH −	Ch -
VOLUME	Volume	+ VOL	Vol +
VOLUME	Volume	VOL −	Vol -
MUTE	Mute	MUTE	Mute
FREEZE	Freeze	II	Pause

Original		Rechange	
MY BUTTON 1	My Button 1	1	1
MY BUTTON 2	My Button 2	2	2
KEYSTONE	Keystone	■	Stop
POSITION	Position	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
◄	Left	◄	Left
ENTER	Enter	OK	Ok
►	Right	►	Right
▼	Down	▼	Down
ESC	Esc	CLEAR EXIT	Exit
RESET	Reset	RETURN BACK	Back

https://telecommandes-mandis.be/fr/Hitachi/1064080-1245-telecommande-de-remplacement-pour-Hitachi-R004-HL02227.html