Mandis shop

LOGITECH LOG005

Original		Rechange	
	Power		Power
HOME	Home	HOME SMART	Smart
HOME	Home	OK	Ok
SEARCH	Search	SEARCH TV/R	TV/R
SLEEP	Sleep	PROG SLEEP	Sleep
REW	Rew	<<	<<
REW	Rew	I<<	I<<
FWD	Fwd	>>	>>
FWD	Fwd	>>I	>>I
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
	Up		Up
	Left		Left
	Right		Right
	Down		Down
VOLUME	Volume+	VOL +	Vol +
VOLUME	Volume-	VOL −	Vol -

Original		Rechange	
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
SHUFFLE	Shuffle	E-MANUAL D.MENU	D. Menu
REPEAT	Repeat	REPEAT TEXT	Text
MORE	More	DISPLAY INFO	Info
NOW PLAYING	Now Playing	APP MEDIA	Media
FAVORITES	Favorites	FAV PRE-CH	Pre Ch