Mandis shop

Samsung DJ9600114S

Original		Rechange		Original	Rechange
Power	Power		Power		
Auto	Auto	1	1		
Recharging	Recharging	SMART	Smart / List		
Spot	Spot	2	2		
Max	Max	3	3		
Start/Stop	Start/Stop	OK	OK		
	Up		Up		
	Right		Right		
	Left		Left		
Manual	Manual	4	4		
Edge	Edge	6	6		
Clock	Clock	MENU	Menu / Home		
Turbo	Turbo	5	5		
Timer/Daily	Timer/Daily	SLEEP	Sleep / Timer		
	Nothing	EXIT	Exit / Cancel / Clear		

https://telecommandes-mandis.be/fr/Samsung/1065688-83449-telecommande-de-remplacement-pour-Samsung-DJ96-00114S.html